



Our 5135 is designed for our Econoflex and Retro Frames. The 5137 is used with our Non-Illuminated and Front Loader Frames. Our 5138 is specially designed for our Non-Illuminated where there is limited access around the frame.

