


Econoflex Profiles

Method for curving profiles.





Do not cut through this leading edge or any part of profile shaded in blue.

Cut distance "P" varies from 20mm to 100mm according to the size of radius required.



STEP 1 - CUT FRAME

(Pitch "P" dependant on required radius "R")



STEP 2 - BEND FRAME

After curving, weld closed end of frame as shown at "W".

Radius Cover #7202 (used for curved boxes)

